

Important Safety Instructions

Read all instructions before using!

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following.

KEEP AWAY FROM WATER!

DANGER! – As with most electrical appliances electrical parts are electrically live even when the switch is off. To avoid any risk:

1. Always unplug immediately after use.
2. Do not use while bathing.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not use near, place in or drop into water or other liquid.

WARNING!

1. An electrical product should never be left unattended when plugged in and in operation.
2. Close supervision is necessary when this product is used by, on or near children or invalids.
3. Use this product only for its intended use as described in this leaflet. Do not use attachments unless recommended by the manufacturer.
4. Never operate this product if it has a damaged cord or plug, if it is not working properly or if it has been dropped into water.
5. Keep cord and product away from heated surfaces. Do not wrap the cord around the product.
6. Never use in bed while sleepy or about to go to bed.
7. Never drop or insert any object into any opening.
8. Do not use outdoors or where moisture is evident.

SPECIAL INSTRUCTIONS

Do not use an extension cord.

USING YOUR BACK & SHOULDER MASSAGER


1. Outfit yourself with the Back & Shoulder-Massager as appropriate and as shown in the picture.
2. Connect the cord of the Massager to the AC Adapter, then plug the AC Adapter into an outlet.
3. Select the desired massage mode/intensity and positioning combination.
4. You may use the Massager either standing, sitting, or laying on a couch.

IMPORTANT SAFETY WARNINGS

- This massage unit is not to be considered a medical device. It is to be used to simply massage you back and shoulders.
- If you are currently undergoing medical treatments, it is strongly advised that you consult your physician before use.
- Always start with lowest power setting.
- If you have any concerns about your health, contact your doctor before using the device.
- Pacemaker patients should not use this device.
- In the unlikely event that you feel pain of the joints or muscles while using the device, it is recommended to discontinue use.

AUTO SHUT-OFF

The Back & Shoulder Massager has a built in thermostat which enables it to automatically shut off after 15 minutes.



REMOTE CONTROL FUNCTIONS:

- HEAT:** Press once to activate the heat function, or twice to switch it off.
POSITION: You can select a specific neck or shoulder region.
ON/OFF Switch
INTENSITY: You may choose between two intensity levels: high, low
PROGRAM SELECTION: Press the button to select on of four different massaging functions.

©2010 MerchSource, LLC. Shift3 and the Shift3 logos are registered trademarks of MerchSource, LLC. All rights reserved.

Distributed by MerchSource, LLC, Foothill Ranch, CA 92610.

For customer support, please visit www.msccustomer care.com or call 1-800-374-2744.

The artwork and design of this manual are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright notice from this manual.

Printed in China